


9. EXPLODED VIEWS AND PARTS LIST

- NOTES:
- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
 - The \triangle mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
 - Screws adjacent to ∇ mark on product are used for disassembly.
 - For the applying amount of lubricants or glue, follow the instructions in this manual. (In the case of no amount instructions, apply as you think it appropriate.)

9.1 PACKING SECTION



1 2 3 4

(1) PACKING SECTION PARTS LIST

<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>	<u>Mark No.</u>	<u>Description</u>	<u>Part No.</u>
⚠ 1	Power Cord	See Contrast table (2)	NSP 8	rekordbox dj license key label	DXA2304
⚠ 2	AC Adapter	DWR1574	NSP 9	Leaflet	DRM1410
3	USB Cable	DDE1128	NSP 10	Warranty	See Contrast table (2)
4	Operating Instructions (Quick Start Guide)	See Contrast table (2)	NSP 11	Polyethylene Bag	AHG7117
			12	Mirror Mat (1200*1000)	DHL1169
5	Operating Instructions (Quick Start Guide)	See Contrast table (2)	13	Handle	DEC3783
6	Operating Instructions (Quick Start Guide)	See Contrast table (2)	14	Spacer	DEC3784
7	Operating Instructions (Quick Start Guide)	See Contrast table (2)	15	Partition	DHC1101
			16	Packing Pad	DHA1972
			17	Packing Pad	DHA1973
			18	Packing Pad	DHA1974
			19	Packing Pad	DHA1975
			20	Packing Case	See Contrast table (2)

(2) CONTRAST TABLE

DDJ-1000/FWLPWXJ, SYXJ, UXJCB and XJCN are constructed the same except for the following:

Mark	No.	Symbol and Description	DDJ-1000 /FWLPWXJ	DDJ-1000 /SYXJ	DDJ-1000 /UXJCB	DDJ-1000 /XJCN	
⚠	1	Power Cord	ADG1154	ADG1154	XDG3052	ADG7079	
	4	Operating Instructions (Quick Start Guide)(En, Es)	DRH1471	Not used	Not used	Not used	
	5	Operating Instructions (Quick Start Guide) (En, Fr, De, It, Ni, Es, Pt, Ru)	Not used	DRH1469	Not used	Not used	
	6	Operating Instructions (Quick Start Guide)(En, Fr)	Not used	Not used	DRH1468	Not used	
	7	Operating Instructions (Quick Start Guide)(Zhc)	Not used	Not used	Not used	DRH1470	
	NSP	10	Warranty	Not used	DRY1270	Not used	Not used
		20	Packing Case	DHG3619	DHG3584	DHG3618	DHG3621

86

DDJ-1000

1 2 3 4