

Connecting the BOSS TONE STUDIO iOS App to the KATANA:GO Unit

© 2024 Roland Corporation

02

For details on how to use BOSS TONE STUDIO, refer to the “Using BOSS TONE STUDIO for KATANA:GO” (BOSS Website).

When using the BOSS TONE STUDIO app in Mainland China

在中国大陆使用BOSS TONE STUDIO时, 因BOSS TONE EXCHANGE部分功能无法使用, 所以您无需查看本手册第4页至第6页的内容。

1. Power-on the KATANA:GO unit and the mobile device.
2. In your mobile device's settings, turn Bluetooth on.



NOTE

Do not tap "KATANA:GO MIDI" if it is shown in the Bluetooth settings of the mobile device. If you tapped this, temporarily cancel the device registration, and perform the procedure again from step 2.

3. Press the [✱] (Bluetooth) button on the KATANA:GO to show the PAIRING screen.

PAIRING

- * If the unit is already connected to a Bluetooth audio device, “🎵: ○ MIDI: X” is shown.


🎵: ○ MIDI: X

Memo

If you want to connect the wireless footswitch FS-1-WL or wireless expression pedal EV-1-WL to the KATANA:GO, refer to “Connecting the KATANA:GO, FS-1-WL and BOSS TONE STUDIO for KATANA:GO at the same time” and “Connecting the KATANA:GO, EV-1-WL and BOSS TONE STUDIO for KATANA:GO at the same time”, in “Using BOSS TONE STUDIO for KATANA:GO” (BOSS website).

4. Start the “BOSS TONE STUDIO for KATANA:GO” app that you installed in your mobile device.

The “Terms of Use” screen is shown.




- * Enable the Bluetooth function and location data when the app prompts you to do so during startup.
- * This screen only appears when the app launches for the first time.
- * For versions before Ver.1.0.2, the BLUETOOTH SETUP screen appears instead of this screen.

5. After reading the “Terms of Use”, tap “AGREE”.

The BLUETOOTH SETUP screen appears.

- * Enable the Bluetooth function and location data when the app prompts you to do so.

6. Tap “CONNECT” as shown on the BLUETOOTH SETUP screen.



- * If more than one KATANA:GO is detected as a connection point, a selection screen appears.
- * If the mobile device was already connected to a KATANA:GO, the mobile device is automatically reconnected to that KATANA:GO, even if more than one KATANA:GO is detected.
- * If “KATANA:GO MIDI” is not shown, tap “SCAN” at the very bottom of the Bluetooth Devices screen, and search again.

7. If “Bluetooth Pairing Request” appears, tap “Pair”.

The editor screen is shown once the connection is made.

If you can't connect

Check each of the following five items one at a time.

1 In the KATANA:GO settings, are you able to connect via Bluetooth?

Press the [✳] button on the KATANA:GO and check whether "PAIRING" or "🎵: ○ MIDI: X" is shown on the screen.

- * If "DISCONNECTED" is shown, press the [✳] button again, and make sure that "PAIRING" is shown on the screen.
- * If "MIDI: ○" is shown, the KATANA:GO is already connected to another mobile device. Long-press the [✳] button on the KATANA:GO to disconnect, or deactivate Bluetooth on your mobile device and try reconnecting (except if connected to the FS-1-WL or EV-1-WL).

2 In step 2 (p. 2) of the procedure, could you have tapped a model name shown on the mobile device?

When you turn the Bluetooth switch on in step 2, "KATANA:GO MIDI" might appear in the device list but you should not tap it. If you tapped it, clear the pairing, and try the procedure again from step 1.

Clearing the pairing

1. Tap the “i” located beside “Connected”, and then “Forget This Device”.



2. Turn the Bluetooth switch off.



3 Turn Bluetooth on and off once again

Turn off the Bluetooth switch on your mobile device and turn it on again.

4 Close all apps, and try the procedure again from step 1 (p. 2)

If you've checked 1–3 and still cannot connect to the app, close all apps that are running on your mobile device.

If paired, remove the pairing.

Closing the app

Use the method that's appropriate for your iOS device to close the apps.

5 Power-off the mobile device and the KATANA:GO unit, and then power them on again

If you've checked 1–4 and still cannot connect to the app, power-off the mobile device and the KATANA:GO, wait for about 10 seconds, and power them on again.

If paired, remove the pairing.

If you've checked items 1–5 and still cannot connect to the app, contact Roland support.