





## LP330/LP330C CAMLOCK™ BONGO STAND MOUNTING INSTRUCTIONS

Congratulations on your purchase of the LP330 or LP330C Camlock Bongo Stand. Products bearing the LP name carry with them an unequaled reputation of design innovation and manufacturing excellence.



1. Lift the cam lever (A) so the lever is raised in the upright position. Place the bongos on the stand so the center block sits squarely against the rubber pads. Be sure the strap is out of the way. (Bongos do not need to be disassembled to attach to the stand.)
2. Feed the strap and hook (C) between the drums shells and over the center block, so that it wraps over the center block. If the hook (D) does not fit through, the strap and hook (C) can be pulled over the drum heads and twisted vertically over the center block and pulled through.
3. Insert the hook (D) into the hook slot (E). If the hook does not reach the slot, loosen or tighten the tension screw (B) until the hook can be inserted. After the hook (C) is inserted, tighten the tension screw (B) until hand tight, then lower the cam lever (A) and tighten the tension screw a few turns and fully lower the cam lever.

**NOTE:** The strap must be tight so bongos do not move while being played.