



KLOWRA EVERLAST DELAY EFFECT

Specific Functions

Press&Hold the Footswitch

• Tap Tempo

The tap tempo is a real-time setting (TIME) synchronized with the BPM by tapping the footswitch, Delivering the delay effect a precise bite to the musical groove. After 5 seconds of inactivity, the LED will turn white, automatically exit the tap tempo function.

• Ramp

Control the fading back and forth between the panel-set and the snap-set to create a dynamic effect. You can adjust the duration of the Ramp by modifying RampATK and RampRLS.

Others

• Stereo Type

Dry/Wet Separation, True Stereo/Ping-pong Stereo

• External Control

Use an external TS/TRS footswitch and expression pedal for multifunctional continuous control

• Bypass Mode

Buffer Bypass (Trail on) or True Bypass (Trail off)

• More Feature Selectable via Power Up Modes

Find more information at www.klowra.com

Description of the LED Button

About LED Color

- White: The current footswitch specific function is Tap tempo
- Blue: Tap tempo is being triggered
- Orange: The current footswitch specific function is Ramp
- Violet: Ramp is being triggered

About Button Function

• Switching of Specific Functions: Press

• Save Snap-set: Press&Hold

Save snap-set by Press&Hold the LED button
Save successfully indicated by LED blinking violet

• Adjustment of Hidden Parameters

Press&Hold, rotate the knob above the hidden parameters

Adjustment successfully indicated by LED blinking yellow

ADAPTER : 9V 250mA POLARITY :

Connect to 9V DC, center negative power supply, 250mA minimum.

NOTE: If the power supply is insufficient, it may cause malfunction. We recommend isolated power supply for your daily operation.

