# 9.7 JOG DIAL (2/2) SECTION



## JOG DIAL (2/2) SECTION PARTS LIST

| Mark | No. | Description | Part No. |
|---|---|---|---|
| | 1 | LCDL Assy | DWX4209 |
| | 1 | LCDR Assy | DWX4210 |
| | 2 | TFT LCD | DWX4226 |
| | 3 | FFC (for L) | DDD1911 |
| | 3 | FFC (for R) | DDD1886 |
| | 4 | FFC (for L) | DDD1912 |
| | 4 | FFC (for R) | DDD1887 |
| | 5 | Sheet (for L) | DEC3815 |
| | 5 | Sheet (for R) | DEC3832 |
| | 6 | Leaf Spring | DBK1391 |
| | 7 | Leaf Spring | DBK1392 |
| | 8 | Slit/JOG | DEC3515 |
| | 9 | Packing | DEC3820 |
| | 10 | Cushion | DEC3831 |
| | 11 | Shaft | DLA2266 |
| | 12 | Bracket/SLT | DNH3168 |
| | 13 | Cover | DNH3391 |
| | 14 | JOG Dial | DNK6820 |
| ⚠ | 15 | Base | DNK6821 |
| | 16 | Holder | DNK6829 |
| | 17 | Holder | DNK6830 |
| | 18 | Roller | DXB2178 |
| | 19 | Leaf Spring | DBK1393 |
| | 20 | Coil Spring | DBH1823 |
| | 21 | Felt | DED1188 |
| | 22 | Lever | DNH3392 |
| | 23 | Lever | DNH3393 |
| | 24 | Gear | DNK6823 |
| | 25 | Cam | DNK6824 |
| | 26 | Pin | DNK6825 |
| | 27 | Cover | DNK6826 |
| | 28 | ••••• | |
| | 29 | ••••• | |
| | 30 | DM Screw (FTC) | DBA1260 |
| | 31 | Screw | AMZ30P060FTC |
| | 32 | Screw | BPZ20P060FTC |
| | 33 | Screw | BPZ26P160FTC |
| | 34 | Screw | BPZ30P080FTC |